

Light Sensor Unit with Photo-resistance

SKU: U021 Vendor: m5stack-store





Product video: https://m5stack.oss-cn-shenzhen.aliyuncs.com/video/Product_example_video/Unit/Light_UNIT.mp4

Description

Unit Light is a light intensity detection sensor. It integrates a photoresistor and a 10K adjustable resistor, capable of detecting light intensity and setting a light intensity threshold. The resistance of the photoresistor decreases as the incident light intensity increases, thus detecting the change in voltage, and obtaining light intensity data through AD conversion. To achieve more accurate light intensity measurements, this Unit also adopts the **LM393** dual differential comparator, used to compare the differential voltage between the photoresistor and the varistor.

Features

- Differential voltage design
- Analog and digital output
- Development Platform: Arduino, UIFlow
- 2 x LEGO compatible holes

Includes

- 1 x Unit Light
- 1 x HY2.0-4P Grove Cable (20cm)

Applications

- Light-controlled switch
- Solar yard lamp
- Infrared surveillance camera

Specifications

Specification	Parameter
Adjustable Resistor	10K
Product Size	32.0 x 24.0 x 8.0mm

Product Weight	4.6g
Package Size	138.0 x 93.0 x 9.0mm
Gross Weight	10.0g

Learn and Documents

[→ DOCUMENTS](#)